

SAFETY INSTRUCTIONS

IMPORTANT SAFEGUARDS:

- This appliance is not intended to be operated using an external timer or separate remote control system.
 - Your appliance is intended for domestic use inside the home only at an altitude below 4000 m. It is not intended to be used in following applications, and the guarantee will not apply for:
 - staff kitchen areas in shops, offices and other working environments;
 - farm houses;
 - by clients in hotels, motels and other residential type environments;
 - bed and breakfast type environments.
 - This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
 - Children must be supervised to ensure that they do not play with the appliance.
 - If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
 - Bread can burn, therefore the appliance must not be used near or below curtains and other combustible materials such as curtains, drapes or wood (shelving, cupboards...) it should be attended when in use.
 - This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children unless they are older than 8 and supervised.
 - Keep the appliance and its cord out of reach of children less than 8 years.
 - Use a (lint free) cloth on parts that come into contact with bread.
 - Make sure you dispose of any crumbs regularly by emptying the crumb-tray which is on the lower part of the toaster.
 - * The temperature of the accessible surfaces may be high when the appliance is in operation. Do not touch the hot surfaces of the appliance.
- * Depending on model
- For your safety, this appliance conforms with applicable standards and regulations (Directives on low voltage, electromagnetic compatibility, materials in contact with foodstuffs, environment, etc.)**
 - In accordance with the CSC notice of 2/12/04, this product features a mechanical design allowing the bread ejection mechanism to be detached from the power cut-off element.**
 - Check that the electricity supply voltage corresponds to the voltage indicated on the appliance (ac current only).
 - Given the many standards in effect, if this toaster is used in a country other than the country where it was purchased, have it checked by an approved service centre (see enclosed after sales service information).
 - Check that the electricity installation is sufficient to supply the power required by this appliance.
 - Always plug the toaster into an earthed socket.
- TO PREVENT ANY ACCIDENTS**
- When using electrical appliances, basic safety precautions should always be followed:
- Carefully read and follow all the instructions for use.
 - The toaster must always be used in the upright position, never on its side or tilted forwards or backwards.
 - Before each use make sure that the crumb tray is fitted correctly.
 - Regularly remove crumbs from the crumb tray.
 - The bread control lever must be in the "Up" position before plugging in or unplugging the appliance.
 - Unplug the appliance if it shows any working abnormalities.
 - Unplug from the power socket when not in use during and before cleaning. Allow to cool down before cleaning or storing.
 - To unplug remove the plug from the wall socket (when the toasting cycle is finished).
 - If the bread jams in the slots after toasting and the elements do not switch off, unplug the plug immediately and wait for the appliance to cool before attempting to remove the bread.
 - Bread can burn, therefore do not use this appliance near any flammable materials such as curtains, under shelving or under wall cupboards.
 - Use on a flat, stable heat-resistant work surface, away from any contact with water and never use underneath a built in kitchen alcove.
- DO NOT:**
- Do not let the toaster operate unattended, particularly when toasting for the first time or when settings have been changed.
 - Do not store the cord or the plug between the slots in the appliance.
 - Do not reheat food items by placing them on top of the toaster. Do not place any saucepans or covers on top of it while the toaster is in operation.
 - Do not unplug the appliance by pulling on the cord.
 - Do not move or carry the appliance during use.
 - Do not leave the appliance within the reach of children.
 - Do not use outdoors. Avoid humid environments.
 - Do not use the appliance for any other use other than that for which it was designed.
 - Do not touch the metal parts or hot surfaces of the appliance when it is working.
 - Oversized foods, metal foil packages, or utensils (spoon, knife, etc.) must not be inserted into a toaster as they may cause an electric shock or fire.
 - Do not use accessory attachments that are not recommended by the manufacturer as this may be dangerous.
 - To protect yourself against and electrical shock do not immerse the cord, plugs, or appliance in water or other liquids.
 - No part whatsoever of your toaster may be washed in the dishwasher or immersed in water.
 - Do not toast breads that may melt (with frosting), sink or fall into the toaster; do not toast food that may fall between the grills (for example: rolls, croutons, blinis, etc.), this could cause damage to the appliance or become a fire hazard.
 - Do not try to toast very thick slices of bread that could become stuck in the toasting slots.
 - Do not use this appliance if:
 - it has a damaged cord.
 - the appliance has been dropped and has visible damage or does not operate properly.
 - In some of these instances, the appliance must be sent to your local approved after-sales service centre to avoid any risk of danger. Refer to the guarantee enclosed.
 - Do not let the cord hang over the edge of the worktop or come into contact with hot surfaces or sharp edges.
 - Do not place on or near a gas burner, electric ring/hob, or near a heated oven.
 - Do not cover this appliance while in use.
 - Do not put paper towels, cardboard or plastic in, on or under the toaster.
 - If flames were to arise from parts of the toaster, never attempt to extinguish them with water. Unplug the appliance and smother the flames with a damp cloth.
 - Do not attempt to dislodge food once the toasting cycle is engaged.
 - Do not use this appliance as a source of heating or drying.
 - Do not use the toaster for cooking, grilling or defrosting frozen food other than bread products.
 - Do not use the appliance to toast bread and warm croissants (or similar products) at the same time (depending on model).
 - The metal frame can become very hot. Do not touch it! Use an oven glove or tongs (depending on model).
 - Do not use any abrasive cleaning agents (no soda-based scouring products, no scouring pads...), no metallic utensils, metal scouring pads etc.
 - For appliances with a metallic finish: Do not use any cleaning products designed for metals: use a soft cloth with a window or glass cleaner.
 - Never hold your toaster by inserting your hands between the bread slots.

SAVE THESE INSTRUCTIONS



Environment protection first !

- Your appliance contains valuable materials which can be recovered or recycled.
- Leave it at a local civic waste collection point.

경우는 예외입니다. 어린이나 장애우가 사용 중일 때에는 반드시 주의 깊게 지켜봐 주십시오.

• 어린이가 사용하는 경우 제품을 가지고 놀지 않도록 반드시 감독해 주십시오.

• 전원코드가 손상된 경우, 위험을 방지하기 위해 반드시 제조사, 지정 서비스 대리점 또는 그에 상응하는 자격을 갖춘 전문가가 교체할 수 있도록 하십시오.

• 화재의 위험이 있으므로, 벽이나 선반아래 혹은 블라인드나 커튼과 같은 가연성이 있는 물체 근처에는 제품을 작동시키지 마십시오.

• 본 제품을 8세 이상의 어린이 또는 신체적, 감각적 또는 정신적 능력이 불완전하거나 경험 및 지식이 결여된 사람이 사용하는 경우, 반드시 감독자가 같이 있거나 안전하게 교육을 받고 관련 위험에 대해 이해하고 난 후에 사용할 수 있도록 하여 주십시오. 어린이는 본 제품을 가지고 놀아서는 안됩니다. 본 제품을 어린이가 사용하기 위해서는 최소 8세 이상이어야 하며 감독자가 함께 있어야 합니다.

• 본 제품과 전원 코드는 8세 미만의 어린이의 손이 닿지 않는 곳에 보관하십시오.

• 빵과 직접 닿는 부분은 먼지 닦는 천을 사용해 청소하여 주십시오.

• 토스터 아래 부분에 있는 빵 부스러기 받침대를 정기적으로 비워 빵 부스러기가 쌓이지 않도록 하십시오.

• * 기기가 작동 중일 때는 닫을 수 있는 표면의 온도가 올라갈 수 있습니다. 기기의 고온 표면에 접촉하지 마십시오.

* 모델에 따라 다름

• 사용자의 안전을 위해, 본 제품은 현행 표준 및 규정을 준수합니다. (저전압, 전자기 적합성, 식품과 접촉하는 물질, 환경 등 관련 법규)

• 2004년 12월 2일 CSC 고지에 따라, 본 제품은 빵 배출 경치가 전력 차단 요소로부터 사용하는 경우, 지정 서비스 센터에서 제품을 확인 받도록 하십시오. (제품에 포함되어 있는 A/S 서비스 정보 참조.)

• 공급 전압이 제품에 표시되어 있는 전압과 동일하게 여부를 확인하십시오. (AC전용)

• 다양한 표준이 시행되고 있는 만큼, 본 토스터 제품을 구입한 국가가 아닌 다른 국가에서 사용하는 경우, 지정 서비스 센터에서 제품을 확인 받도록 하십시오. (제품에 포함되어 있는 A/S서비스 정보를 참고하십시오.)

• 설치된 전원이 본 제품이 요구하는 전력을 공급하기에 충분한지 확인하십시오.

• 토스터는 항상 접지된 소켓에 연결하십시오.

사고를 예방하기 위해

전기제품을 사용할 때에는 다음과 같은 기본적인 안전상의 주의사항을 준수해 주십시오.

준수사항

• 사용설명서를 주의 깊게 읽어주십시오.

• 사용 방법 설명을 빠짐없이 읽고 그대로 따라 주십시오.

• 토스터를 어린이가 사용하거나, 어린이와 가까운 곳에서 사용할 때 또는 사용 방법에 익숙하지 않고 장애가 있는 사람이 사용하는 경우, 사용법을 잘 알고 있는 성인의 주의 깊은 감독 하에서만 사용하도록 해야 합니다.

• 토스터는 항상 똑바로 세운 상태로 사용해야 하며, 절대로 옆으로 놓거나 앞, 뒤로 기울인 상태로 사용해서는 안됩니다.

• 매번 사용할 때마다, 부스러기 받침대가 제대로 끼워져 있는지 확인하십시오.

• 정기적으로 빵 부스러기 받침대를 비우도록 하십시오.

• 토스터의 전원플러그를 꺼거나 빼기 전에는 반드시 급기 작동레버가 본래의 위치에 있어야 합니다.

• 토스터가 제대로 작동하지 않는 경우에는 반드시 전원 플러그를 뽑아 주십시오.

• 청소하는 동안, 청소하기 전, 토스터를 사용하지 않은 때에는 전원 소켓에서 플러그를 뽑아 두십시오. 청소 또는 보관하기 전에 반드시 토스터가 식물 때까지 기다리도록 하십시오.

• 플러그를 뽑을 때는 (토스터 작동이 끝나면) 벽 소켓에서 플러그를 뽑도록 하십시오.

• 토스팅이 끝난 후에도 빵이 빵 투입구에 끼어서 토스터가 깨지지 않는 경우, 즉시 플러그를 뽑은 다음 토스터가 식기를 기다렸다가 빵을 끌어내도록 하십시오.

• 빵이 탈 수 있기 때문에, 토스터를 커튼, 선반 밑 또는 벽 천장 아래 등 일체의 가연성 물질을 근처에서 사용하지 마십시오.

• 토스터는 물이 일체 닿지 않는, 평평하고, 안정성이 있고, 내열성이 있는 작업대 위에 놓고 사용하고 절대 불박이장 아래 협소한 공간에서 사용하지 마십시오.

주의사항:

• 토스터를 작동시켜 두고 자리를 비우지 마십시오. 특히, 구입 후 처음 사용하시거나 설정을 변경한 후에는 반드시 지켜봐 주십시오.

• 전원코드나 플러그를 토스터의 빵 투입구(빵을 넣는 구멍) 사이에 보관하지 마십시오.

• 빵 음식물을 토스터 위에 올려 놓고 데우지 마십시오. 토스터가 사용 중일 경우, 토스터 위에 뚜껑이나 다른 제품을 올려 놓지 마십시오.

• 플러그를 뽑을 때 절대로 코드를 잡아당기지 마십시오.

• 사용 중에 토스터를 움직이거나 이동시키지 마십시오.

• 실외에서 사용하지 마십시오. 습한 곳에서 사용하지 마십시오.

• 토스터를 원래 설계 목적 외에 다른 용도로 사용하지 마십시오.

• 토스터 사용 중에 금속 부분 또는 뜨거운 표면을 만지지 마십시오.

• 빵 토스팅 기기보다 큰 음식, 호텔 포장, 또는 (스푼, 나이프 등) 식사 도구 등을 감전 또는 화재를 일으킬 수 있으므로 절대 토스터에 넣어서는 안됩니다.

• 제조사가 권장하지 않는 액세서리는 위험할 수 있으므로 사용하지 마십시오.

• 감전 위험을 방지하기 위해 전기코드, 플러그 또는 제품을 물이나 기타 액체에 담그지 마십시오.

• 토스터기의 어떤 부품도 식기세척기로 세척하거나 물에 담그지 마십시오.

• 놀을 수 있거나 그릴로 홀려내거나 그릴 사이로 떨어질 수 있는 재떨류(글리사주 타르트, 미니 케이크, 크루통, 블리니 등)에 사용하지 마십시오. 이 경우 기기 손상 또는 화재를 초래할 수 있습니다.

• ▲ 지나치게 두꺼운 빵은 토스터의 빵 투입구에 끌 수 있으므로 토스터에 넣지 마십시오.

• 다음의 경우 토스터를 사용하지 마십시오.

- 전기 코드가 손상된 경우

- 토스터를 떨어뜨렸는데 눈에 보이게 손상되었거나 제대로 작동되지 않는 경우

이러한 경우, 일체의 위험을 방지하려면 반드시 제품을 가까운 지정 서비스 센터에 보내셔야 합니다. 제품에 들어있는 보증서를 참고하십시오.

• 코드가 작업대 가장자리로 늘어지거나 뜨거운 표면에 닿지 않도록 하십시오.

• 사용 중인 제품을 뒤집지 마십시오.

• 토스터 안, 위 또는 아래에 종이타일, 마분지 또는 플라스틱으로 된 물건을 놓지 마십시오.

• ▲ 토스터 일부에서 불꽃이 일어나는 경우, 절대 물을 부어 끄려고 하지 마십시오. 제품 전원코드를 뽑은 다음

• 일단 토스터의 작동이 시작된 후에는 빵을 꺼내려 하지 마십시오.

• 토스터를 빵 제품이 아닌 다른 냉동 식품의 조리, 그릴구이 또는 해동 용도로 사용하지 마십시오.

• 빵을 토스터 하면서 동시에 크로와상(그와 비슷한 베이커리류)을 데우는 데 사용하지 마십시오(모델에 따라 다름).

• 금속 프레임은 매우 뜨거워질 수 있습니다. 절대 만지지 마십시오. 오븐 장갑이나 집게를 사용하도록 하십시오(모델에 따라 다름).

• 부식성 세제(소다 원료 세제제, 강력 세제 등)는 사용하지 마십시오.

• 금속소재로 마감 처리된 제품의 경우, 금속 제품용으로 만들어진 세제제를 일체 사용하지 마십시오. 창문 또는 유리 세제제를 사용해 부드러운 천으로 닦도록 하십시오.

• ▲ 토스터가 이동할 때에는 빵 투입구에 손을 집어 넣지 않도록 주의하십시오.

본 설명서를 잘 보관하여, 필요 시 활용하여 주십시오.

환경을 생각합니다!

① 본 제품에는 재활용 할 수 있는 부품들이 있습니다.

② 수명이 끝난 제품을 폐기하실 때는 분리수거를 하십시오.

제품문의 080-733-7878

AS문의 1588-1588(전국 어디서나)

www.tefal.co.kr

ไทย

คำแนะนำ(환경보호)

가능한 깊은 틈을 두고 사용하세요.

• 올바른 원칙을 기준으로 했을 때, 햇빛을 차단하는 틈을 두고 사용하세요.

• 올바른 원칙을 기준으로 했을 때, 햇빛을 차단하는 틈을 두고 사용하세요.

• 올바른 원칙을 기준으로 했을 때, 햇빛을 차단하는 틈을 두고 사용하세요.

• 올바른 원칙을 기준으로 했을 때, 햇빛을 차단하는 틈을 두고 사용하세요.

• 올바른 원칙을 기준으로 했을 때, 햇빛을 차단하는 틈을 두고 사용하세요.

• 올바른 원칙을 기준으로 했을 때, 햇빛을 차단하는 틈을 두고 사용하세요.

• 올바른 원칙을 기준으로 했을 때, 햇빛을 차단하는 틈을 두고 사용하세요.

• 올바른 원칙을 기준으로 했을 때, 햇빛을 차단하는 틈을 두고 사용하세요.

• 올바른 원칙을 기준으로 했을 때, 햇빛을 차단하는 틈을 두고 사용하세요.

• 올바른 원칙을 기준으로 했을 때, 햇빛을 차단하는 틈을 두고 사용하세요.

• 올바른 원칙을 기준으로 했을 때, 햇빛을 차단하는 틈을 두고 사용하세요.

• 올바른 원칙을 기준으로 했을 때,

